

sample taking tap water



Why?

You want information about the heavy metal content in the water pipes in your house.

First step

Let the water run until for 1 liter.

And then?

Take a clean sample vessel, a glass bottle or a plastic container .



After that?

Print out the order form or create a note with the order number and pack it together with the sample in a box.

Next step?

Close the sample vessel. Make sure that it is really closed tight.

Amount of sample?

We will need a minimum of 250 mL.



Finally.

Send the package to my-lab International.

Questions?

If you need any further information, please do not hesitate to contact us.

my-lab International

Your sample will be analyzed and we will create an easily understandable report. The report will be sent by e-mail a few days after receipt of the sample.