

sample taking tap water



Why?

You want information about the heavy metal content in the water pipes in your house.



First step

Let the water run until the temperature is constant.



And then?

Take a clean sample vessel, a glass bottle or a plastic container .



After that?

Print out the order form or create a note with the order number and pack it together with the sample in a box.



Next step?

Close the sample vessel. Make sure that it is really closed tight.



Amount of sample?

We will need a minimum of 250 mL.



Finally.

Send the package to my-lab International.

Questions?

If you need any further information, please do not hesitate to contact us.



my-lab International

Your sample will be analyzed and we will create an easily understandable report. The report will be sent by e-mail a few days after receipt of the sample.